


From Lab to Practical: An ammonia-powered Fuel Cell Electric Golf Cart System

Ammonia (NH₃) is a carbon-free hydrogen (H₂) carrier, which enables liquid-phase H₂ storage and transport under mild conditions. Although the concept of NH₃-to-H₂ has been frequently proposed, the practical application of NH₃ as the energy source for H₂ power automotive systems is rarely reported. To close the gap between NH₃ supply and H₂ utilization, we demonstrated an NH₃-powered fuel cell electric golf cart as a proof of concept. The integration of NH₃ cracker (installed with catalyst), gas purifier, fuel cell, and energy management system formed a successful powertrain that could thrust a golf cart into motion. The catalytic performance of both nickel (Ni) and iron (Fe)-based catalysts was measured (cracker gas evolution monitored by HPR-20 EGA, Hiden), and the optimal catalyst demonstrated a > 99.9% NH₃ conversion at 600 °C. The gas purifier was confirmed to be capable of removing the residual NH₃ for a proton exchange membrane fuel cell (PEMFC). The fuel cell, when powered by the cracked and purified gas mixture, revealed comparable performance and power output as compared with the pre-mixed fuel gas mixture (75%H₂/25%N₂), demonstrating the feasibility of the whole system. The demonstrated NH₃-powered fuel cell prototype with an energy level of 17.5 kWh gives total system-specific energy of 379.4 Wh/kg. When equipped with 15 kg NH₃, the integrated power system is expected to meet the US Department of Energy's 2020 gravimetric hydrogen capacity target for onboard automotive hydrogen storage systems. During the operation, only N₂ and water are generated in the chemical processes of the system and emitted into the atmosphere, demonstrating that this power-generating technology is clean and carbon-free. Our proof-of-concept prototype represents an innovative demonstration of the NH₃-powered fuel cell vehicle system, giving rise to a future reference and inspiration for the practical developments of NH₃-based H₂ fuel applications.



Project summary by: Molly Meng-Jung Li, Department of Applied Physics, The Hong Kong Polytechnic University, Hung Hom, Hong Kong, China



THE HONG KONG
POLYTECHNIC UNIVERSITY
香港理工大學



DEPARTMENT OF
APPLIED PHYSICS
應用物理學系



Department of
Electrical Engineering
機工程學系

Paper Reference: "From lab to practical: An Ammonia-powered fuel cell electric golf cart system"
Chemical Engineering Journal (2023) 452, Part 2, 139390

Hidden Product: [HPR-20 EGA](#)